

CAMP L1

Latarka, lampa campingowa i powerbank 3w1



syncrotech
NOMAD

CAMP L1

3-in-1 Flashlight, Camping Lantern & Power Bank

Instrukcja obsługi

Polski

Przeznaczenie

Syncrotech NOMAD CAMP L1 to przenośna latarka i lampa campingowa LED przeznaczona do użytku podczas campingu, podróży, pracy w terenie oraz jako oświetlenie awaryjne.

Obsługa

Przedni reflektor LED

Naciśnij przycisk ON/OFF, aby przełączać tryby pracy:

- słabsze światło,
- mocniejsze światło,
- stroboskop,
- wyłączenie.

Oświetlenie campingowe

Obracaj pokrętkę regulacji jasności, aby płynnie regulować intensywność światła. Lampa umożliwia korzystanie ze światła:

- ciepłego,
- białego,
- ciepłego i białego jednocześnie.

Ładowanie

- Ładować wyłącznie przy użyciu zasilacza 5 V / 1 A.
- Port USB-C służy do ładowania akumulatora.
- Podczas ładowania wskaźnik baterii miga.
- Po pełnym naładowaniu wszystkie segmenty świecą światłem ciągłym.

Funkcja powerbanku

Port USB-A umożliwia zasilanie lub awaryjne ładowanie urządzeń zewnętrznych, takich jak telefon komórkowy.

Wskaźnik baterii

Cztery segmenty wskazują orientacyjny poziom naładowania:

25% • 50% • 75% • 100%

Ostrzeżenia

- Nie kierować światła bezpośrednio w oczy.
- Nie zanurzać lampy w wodzie.
- Nie demontować urządzenia ani akumulatora.
- Chronić przed wysoką temperaturą i ogniem.



User Manual

English

Intended use

The Syncrotech NOMAD CAMP L1 is a portable LED flashlight and camping lantern designed for camping, travelling, outdoor work and emergency lighting.

Operation

Front Spotlight

Press the ON/OFF button to switch between:

- Low beam
- High beam
- Strobe
- Off

Camping light

Rotate the brightness control knob to adjust the light output continuously. The lantern offers:

- Warm light
- White light
- Warm and white light together

Charging

- Charge only with a 5 V / 1 A USB power source.
- Use the USB-C port for charging.
- The battery indicator flashes while charging.
- All indicator LEDs remain on when charging is complete.

Power bank function

The USB-A output can be used to power or charge external USB devices such as a mobile phone.

Battery indicator

Four LEDs indicate the approximate battery level:

25% • 50% • 75% • 100%

Safety information

- Do not shine the light directly into eyes.
- Do not immerse the product in water.
- Do not disassemble the product or the battery.
- Keep away from fire and excessive heat.

